

Lily User Instructions

Back Height Adjustment

1



Lean forward and grasp the back on either side. Pull up until the pronounced lumbar support of the chair is aligned with your own lumbar region, which is just below your waist.

The back will stop in any one of four positions.

Back Tilt

2



To unlock the back of the chair and allow it to move with your body lift the paddle found under the left hand side of your seat. To adjust the tension to suit your own weight pull out the knob under the right hand side of the seat and grasping it with an over-hand grip, rotate it forward to increase the tension and back to decrease the tension.

Seat Height

3



Lift the paddle located under the right hand side of your seat whilst lifting your weight out of the chair to allow the seat to raise to the desired height.

To lower the height, lift the paddle again leaving your body weight on the seat.

Seat Slide

4



Push the button on the right hand side of the seat. Keep your weight on the seat pad and move forward.

Release the button to lock the seat.

Arm Pad Adjustment

5



Lift the buttons on the outside of the arm risers to raise and lower the arms. Ensure that both arm pads are the same height.

 The width can be adjusted using the 'quick-release' handles under the arm supports.



boss
design

Boss Design
Boss Drive
Dudley
DY2 8SZ

T: +44(0)1384 455570
F: +44(0)1384 241628

sales@bossdesign.com
www.bossdesign.com

London Showroom
7 Clerkenwell Road
London
EC1M 5PA

T: +44(0)20 7253 0364
F: +44(0)20 7608 0160